



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-03	DRAG KNOB ASSEMBLY	30	2E1-050-01	A20-060 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	31	2F5-436-01	ROLLER CLUTCH RETAINER
3	2W2-071-01	KEY WASHER	32	2Q2-021-01	SPRING
4	2W1-226-01	080-260 WASHER	33	2YZ-027-01	ONE-WAY CLUTCH BEARING ASSEMBLY
5	2W3-035-01	EARED WASHER	34	2A4-082-01	ONE-WAY CLUTCH INNER TUBE
6	2YT-443-03	SPOOL TOTAL ASSEMBLY	35	2Z1-005-07	816-5 BALL BEARING
7	2W2-016-01	KEY WASHER	36	2G2-165-01	PINION GEAR
8	2Z1-029-07	408-3 BALL BEARING	37	2E1-051-01	D30-080 SCREW
9	2C1-119-01	SPACER	38	2B1-173-01	BODY
10	2W1-237-01	070-225 WASHER	39	2Z1-009-07	711-3 BALL BEARING
11	2L3-015-01	CLICK LEAF SPRING	40	2G1-150-01	DRIVE GEAR
12	2M3-151-01	MAIN SHAFT	41	2W1-019-01	071-103 WASHER
13	2F8-019-02	CLICK LEAF SPRING HOLDER	42	2Z1-023-07	814-4 BALL BEARING
14	2W2-015-01	KEY WASHER	43	2M2-016-01	OSCILLATING CAM
15	2E3-002-01	ROTOR NUT	44	2G3-081-01	OSCILLATING GEAR
16	2E1-036-01	B26-040 SCREW	45	2M1-074-01	OSCILLATING SLIDER
17	2R1-146-03	ROTOR	46	2E2-009-01	F23M-060 SCREW
18	2R4-203-02	BAIL TRIP COVER	47	2B2-126-03	BODY COVER
19	2E1-065-01	B22-065 SCREW	48	2E1-055-01	A26-100 SCREW
20	2E2-094-01	B30M-090 SCREW	49	2YH-335-02	HANDLE TOTAL ASSEMBLY
21	2R2-070-03	BAIL ARM	50	2C3-042-01	HANDLE SCREW SLEEVE
22	2E1-010-01	b30-100 SCREW	51	2H6-001-13	HANDLE SCREW CAP
23	2W1-258-01	030-060 WASHER	52	2A2-106-03	ANTI-REVERSE CAM
24	2Z1-012-07	407-2.5 BALL BEARING	53	2L5-010-01	ANTI-REVERSE CAM SPRING
25	2R6-020-02	LINE ROLLER	54	2F5-435-02	REAR COVER
26	2YL-158-03	BAIL ASSEMBLY	55	2E1-020-02	B22-055 SCREW
27	2Q1-051-02	BAIL SPRING	LD3500	SPECIAL PARTS	
28	2R5-179-01	BAIL TRIP LEVER	6	2YT-459-03	SPOOL TOTAL ASSEMBLY
29	2R4-202-02	BAIL SPRING COVER			