




SALTWATER REEL

SEASPIRIT SP458R / SP558R

Please order by parts number, not key number
 Bitte, Best.-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)



Key NO.

Parts No.

Parts name

59-64	2YT-312-01	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-178-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-02	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2E3-048-01	CAST CONTROL NUT
12	2W5-029-01	CAST CONTROL SPACER
13	2E9-005-01	O RING
14	2S3-022-02	CLUTCH LEVER
15	2E1-009-01	A30-100 SCREW
16	2F5-295-07	RIGHT SIDE COVER
17	2Q3-099-01	CLUTCH SPRING
18	2A2-069-01	CLUTCH CAM
19	2E1-014-01	B40-100 SCREW
20	2C1-088-01	DRIVE SHAFT COLLAR
21	2F6-092-01	HOLDING PLATE
22	2E1-036-01	B26-040 SCREW
23	2Z2-017-01	BUSHING
24	2W2-054-01	KEY WASHER
25	2W3-030-01	EARED WASHER
26	2W2-053-01	KEY WASHER
27	2W1-192-01	090-340 WASHER
28	2G1-088-01	DRIVE GEAR
29	2W1-173-01	081-140 WASHER
30	2M3-079-01	DRIVE SHAFT
31	2Q3-081-01	ONE-WAY CLUTCH SPRING
32	2YF-082-01	ANTI-REVERSE RATCHET A
33	2YA-026-01	ANTI-REVERSE RATCHET B
34	2W1-169-01	061-120 WASHER
35	2E5-028-01	E4.0 RETAINER
36	2E1-020-02	B22-055 SCREW
37	2F6-090-02	BODY SPACER
38	2YG-019-01	PINION GEAR ASSEMBLY
39	2Q1-080-01	YOKE SPRING
40	2A2-068-01	PINION YOKE
41	2F6-091-01	CLUTCH PAWL
42	2P4-013-01	LEVEL WIND GUIDE
43	2E1-066-01	A20-100 SCREW
44	2Q2-009-01	CLICK PAWL SPRING
45	2A4-064-01	ANTI-REVERSE PAWL

Key NO.

Parts No.

Parts name

46	2P1-036-01	ANTI-REVERSE PAWL PIN
47	2YB-168-02	BODY ASSEMBLY
48	2E5-013-01	E3.0 RETAINER
49	2W1-046-01	051-068 WASHER
50	2G3-050-01	COUNTER GEAR
51	2C2-074-01	WORM SHAFT BUSHING
52	2E3-014-01	LINE GUIDE NUT
53	2W1-100-01	020-068 WASHER
54	2M5-005-01	LINE GUIDE PIN
55	2YR-063-01	LINE GUIDE ASSEMBLY
56	2C4-019-01	LEVEL WIND GUARD
57	2W1-087-01	060-080 WASHER
58	2YM-058-01	WORM SHAFT ASSEMBLY
59	2YS-208-01	SPOOL ASSEMBLY
60	2Z1-035-05	917-5 BALL BEARING
61	2W1-097-01	059-100 WASHER
62	2F3-052-01	CLICK GEAR
63	2G3-075-01	SPOOL GEAR
64	2E5-006-01	E2.5 RETAINER
65	2W1-097-01	059-100 WASHER
66	2W5-015-01	CAST CONTROL SPACER
67	2E1-048-01	B22-080 SCREW
68	2F2-020-01	CLICK SPRING
69	2F4-019-01	CLICK PAWL
70	2F5-294-14	LFET SIDE COVER
71	2W5-040-01	CLICK SWITCH WASHER
72	2F7-006-01	CLICK SWITCH
73	2E2-007-01	B30M-100 SCREW
74	2G3-076-01	SPOOL GEAR
75	2E3-049-01	IDLE GEAR SHAFT
76	2F6-093-01	CLUTCH PAWL RETAINER
77	2E3-058-02	SIDEPLATE HOLDING NUT
78	2E2-043-01	X50M-400 SCREW
79	2E3-022-01	ROD CLAMP BOLT
80	2F6-029-01	ROD CLAMP
81	2E3-023-01	WING NUT
SP558R SPECIAL PARTS		
59-64	2YT-314-01	SPOOL TOTAL ASSEMBLY
16	2F5-295-08	RIGHT SIDE COVER
42	2P4-013-02	LEVEL WIND GUIDE
47	2YB-169-02	BODY ASSEMBLY
56	2C4-019-02	LEVEL WIND GUARD
58	2YM-060-01	WORM SHAFT ASSEMBLY
59	2YS-210-01	SPOOL ASSEMBLY
70	2F5-294-16	LEFT SIDE COVER