




# SALTWATER REEL SEASPIRIT

Please order by parts number, not key number  
 Bitte, Best.-Nr. angeben (Nicht "key" -nr.)  
 Veuillez indiquer le numero de la piece (Non "key" no.)

## SS458R/C-ft / SS458R/C-M SS558R/C-ft / SS558R/C-M



**Key NO.**

66-71

**Parts No.**

**Parts name**

1	2YT-311-01	SPOOL TOTAL ASSEMBLY
2	2E2-006-01	B26M-050 SCREW
3	2F6-043-01	ROTOR NUT HOLDING PLATE
4	2E3-027-01	HANDLE NUT
5	2YH-148-01	HANDLE TOTAL ASSEMBLY
6	2W2-044-01	KEY WASHER
7	2YD-046-01	STAR DRAG LEVER ASSY
8	2L3-025-01	CLICK LEAF SPRING
9	2W2-043-01	KEY WASHER
10	2F8-060-01	CLICK LEAF SPRING HOLDER
11	2L1-007-01	SPRING WASHER
12	2Z1-023-05	814-4 BALL BEARING
13	2E3-048-01	CAST CONTROL NUT
14	2W5-029-01	CAST CONTROL SPACER
15	2E9-005-01	O RING
16	2S3-022-01	CLUTCH LEVER
17	2E1-009-01	A30-100 SCREW
18	2YF-107-03	RIGHT SIDE COVER ASSEMBLY
19	2Q3-099-01	CLUTCH SPRING
20	2A2-069-01	CLUTCH CAM
21	2E1-014-01	B40-100 SCREW
22	2F8-072-01	ANTI-REVERSE RATCHET SET
23	2Y2-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
24	2F6-092-01	HOLDING PLATE
25	2E1-036-01	B26-040 SCREW
26	2Z2-017-01	BUSHING
27	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
28	2W2-054-01	KEY WASHER
29	2W3-030-01	EARED WASHER
30	2W2-053-01	KEY WASHER
31	2W1-192-01	090-340 WASHER
32	2G1-088-01	DRIVE GEAR
33	2W1-173-01	081-140 WASHER
34	2M3-079-01	DRIVE SHAFT
35	2Q3-081-01	ONE-WAY CLUTCH SPRING
36	2YF-082-01	ANTI-REVERSE RATCHET A
37	2YA-026-01	ANTI-REVERSE RATCHET B
38	2W1-169-01	061-120 WASHER
39	2E5-028-01	E4.0 RETAINER
40	2YF-085-01	COUNTER ASSEMBLY
41	2E1-016-02	B26-080 SCREW
42	2E1-020-02	B22-055 SCREW
43	2F6-089-01	BODY SPACER
44	2E1-066-01	A20-100 SCREW
45	2YG-019-01	PINION GEAR ASSEMBLY
46	2Q1-080-01	YOKE SPRING
47	2A2-068-01	PINION YOKE
48	2F6-091-01	CLUTCH PAWL
49	2P4-013-01	LEVEL WIND GUIDE
50	2Q2-009-01	CLICK PAWL SPRING
51	2A4-064-01	ANTI-REVERSE PAWL
52	2P1-036-01	ANTI-REVERSE PAWL PIN
53	2C1-084-01	COUNTER GEAR COLLAR
54	2G3-077-01	COUNTER GEAR A
55	2YB-168-01	BODY ASSEMBLY

**Key NO.**

55

**Parts No.**

**Parts name**

55	2E5-013-01	E3.0 RETAINER
56	2W1-046-01	051-068 WASHER
57	2G3-050-01	COUNTER GEAR
58	2C2-074-01	WORM SHAFT BUSHING
59	2E3-014-01	LINE GUIDE NUT
60	2W1-100-01	020-068 WASHER
61	2M5-005-01	LINE GUIDE PIN
62	2YR-063-01	LINE GUIDE ASSEMBLY
63	2C4-019-01	LEVEL WIND GUARD
64	2W1-087-01	060-080 WASHER
65	2YM-058-01	WORM SHAFT ASSEMBLY
66	2YS-207-01	SPOOL ASSEMBLY
67	2Z1-035-05	917-5 BALL BEARING
68	2W1-097-01	059-100 WASHER
69	2F3-052-01	CLICK GEAR
70	2G3-075-01	SPOOL GEAR
71	2E5-006-01	E2.5 RETAINER
72	2W1-097-01	059-100 WASHER
73	2W5-015-01	CAST CONTROL SPACER
74	2E1-048-01	B22-080 SCREW
75	2F2-020-01	CLICK SPRING
76	2F4-019-01	CLICK PAWL
77	2F5-294-09	LEFT SIDE COVER
78	2W5-040-01	CLICK SWITCH WASHER
79	2F7-006-01	CLICK SWITCH
80	2E2-007-01	B30M-100 SCREW
81	2G3-076-01	SPOOL GEAR
82	2E3-049-01	IDLE GEAR SHAFT
83	2F6-093-01	CLUTCH PAWL RETAINER
84	2E3-058-01	SIDEPLATE HOLDING NUT
85	2E2-043-01	X50M-400 SCREW
86	2E3-022-01	ROD CLAMP BOLT
87	2F6-029-01	ROD CLAMP
88	2E3-023-01	WING NUT
39	<b>SS458R/C-M</b>	<b>SPECIAL PARTS</b>
	2YF-085-02	COUNTER ASSEMBLY
66-71	<b>SS558R/C-ft</b>	<b>SPECIAL PARTS</b>
17	2YT-313-01	SPOOL TOTAL ASSEMBLY
48	2YF-107-04	RIGHT SIDE COVER ASSEMBLY
54	2P4-013-02	LEVEL WIND GUIDE
63	2YB-169-01	BODY ASSEMBLY
65	2C4-019-02	LEVEL WIND GUARD
66	2YM-060-01	WORM SHAFT ASSEMBLY
77	2YS-209-01	SPOOL ASSEMBLY
	2F5-294-11	LEFT SIDE COVER
66-71	<b>SS558R/C-M</b>	<b>SPECIAL PARTS</b>
17	2YT-313-01	SPOOL TOTAL ASSEMBLY
39	2YF-107-04	RIGHT SIDE COVER ASSEMBLY
48	2YF-085-02	COUNTER ASSEMBLY
54	2P4-013-02	LEVEL WIND GUIDE
63	2YB-169-01	BODY ASSEMBLY
65	2C4-019-02	LEVEL WIND GUARD
66	2YM-060-01	WORM SHAFT ASSEMBLY
77	2YS-209-01	SPOOL ASSEMBLY
	2F5-294-11	LEFT SIDE COVER