



Key	NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
	1	2S3-017-01	LOW SPEED BUTTON SHAFT	48	2Q1-061-011	YOKE SPRING
	2	2E2-078-01	h30M-070 SCREW	49	2G1-074-01	DRIVE GEAR A
	3	2F8-077-01	VARIABLE SPEED BUTTON STAND	50	2E5-024-01	C12 RETAINER
	4	2Q1-074-01	SLIDE PLATE SPRING	51	2M3-057-01	DRIVE SHAFT
	5	2S3-015-01	HI-SPEED SLIDE PLATE	52	2A2-062-01	YOKE
	6	2E0-021-01	HANDLE BOLT	53	2YG-011-01	DRIVE GEAR B ASSEMBLY
	7	2C1-065-01	BUTTON SHAFT COLLAR	54	2E5-033-01	C15 RETAINER
	8	2E2-031-01	A26M-075 SCREW	55	2A2-022-01	DRAG CAM
	9	2YH-172-01	HANDLE TOTAL ASSEMBLY	56	2F8-086-01	BEARING HOLDER
	10	2F5-136-01	DRIVE GEAR SHAFT COVER	57	2P1-018-01	DRAG CAM PIN
	11	2E9-012-01	WATER PROOF RING	58	2E0-037-01	PRESET SCREW
	12	2Q1-060-01	BUTTON SHAFT SPRING	59	2L1-012-01	SPRING WASHER
	13	2P4-010-01	BUTTON SHAFT SPACER BAR	60	2C1-087-01	COLLAR
	14	2Z1-034-05	1019-7 BALL BEARING	61	2Z1-036-05	617-6 BALL BEARING
	15	2D1-031-01	PRESET DRAG KNOB	62	2YG-022-01	PINION GEAR ASSEMBLY
	16	2Q1-089-01	COMPRESSION SPRING	63	2E2-056-01	F30M-060 SCREW
	17	2W1-182-01	071-100 WASHER	64	2F3-056-01	CLICK PLATE
	18	2L3-035-01	CLICK LEAF SPRING	65	2YD-062-01	BRAKE DISC ASSY(R)
	19	2F8-085-01	CLICK LEAF SPRING HOLDER	66	2W1-020-01	081-130 WASHER
	20	2F5-253-01	FIGHTING LEVER COVER	67	2L1-013-01	SPRING WASHER
	21	2W1-077-01	075-140 WASHER	68	2E9-023-01	WATER PROOF RING
	22	2E5-018-01	E6.0 RETAINER	69	2YS-243-01	SPOOL ASSEMBLY
	23	2W1-153-01	140-226 WASHER	70	2E9-022-01	WATER PROOF RING
	24	2D4-016-01	FIGHTING LEVER	71	2Q1-088-01	DRAG SPRING
	25	2F5-120-01	BUTTON CAP	72	2YD-061-01	BRAKE DISC ASSY(L)
	26	2Q1-028-01	BUSH BUTTON SPRING	73	2F5-250-01	BRAKE DISC COVER
	27	2S3-014-01	PUSH BUTTON	74	2E2-030-02	F20M-050 SCREW
	28	2YP-001-01	CLICK PIN ASSEMBLY	75	2A4-059-02	ANTI-REVERSE PAWL
	29	2C1-074-01	SPACER	76	2E2-004-01	B30M-060 SCREW
	30	2F8-076-01	CLICK HOLD	77	2E8-004-01	STARWASHER
	31	2W1-074-01	147-226 WASHER	78	2L5-015-01	PAWL SPRING
	32	2E2-077-01	h30M-160 SCREW	79	2E2-068-02	F20M-065 SCREW
	33	2F5-252-01	DRAG LEVER QUADRANT	80	2F6-081-02	HARNES LUG (R)
	34	2C1-073-01	QUADRANT SPACER	81	2E2-065-01	B26M-140 SCREW
	35	2F5-335-01	CLICK SWITCH COVER	82	2F6-080-02	HARNES LUG (L)
	36	2E5-006-01	E2.5 RETAINER	83	2Z1-040-05	819-6 BALL BEARING
	37	2W1-204-01	034-065 WASHER	84	2W5-049-01	HARNES LUG(L) SPACER
	38	2Q1-102-01	CLICK PLUNGER SPRING	85	2YB-209-01	BODY ASSEMBLY
	39	2F7-009-01	CLICK SWITCH	86	2W5-027-01	STAND GASKET
	40	2C1-102-01	CLICK PIN BUSHING	87	2F8-045-03	REEL FOOT
	41	2E2-076-01	h40M-200 SCREW	88	2E2-062-01	H40M-110 SCREW
	42	2YF-093-02	RIGHT SIDE COVER ASSEMBLY	89	2E0-038-01	CLAMP SCREW
	43	2E3-067-01	CLICK BUSHING NUT	90	2YF-138-01	ROD CLAMP ASSEMBLY
	44	2Q1-063-01	CLICK BUTTON SPRING	91	2X3-010-01	WRENCH
	45	2P1-062-03	CLICK PIN	92	2X3-006-01	WRENCH
	46	2Z1-037-05	1221-7 BALL BEARING	93	2X3-007-01	HEX WRENCH
	47	2W1-128-01	121-150 WASHER	94	2X3-009-01	HEX WRENCH