



Should Geared Clutch (8) drop out while changing spool, be sure to interlock with Clutch Pinion (23) to reassemble.

Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	DJ324-03A	Front Cover Assy. (Gold)	18	DJ067-01D	Crank Rod	26	DJ769-01A	Crank Rod Nut (Gold)
2	DJ310-01E	Spinner Head Assy.	14	CJ026-01B	Crank Bearing	27	DJ190-01D	Oscillator Gear
3	DJ034-01J	Spool Clip	15	DJ032-01H	Clutch Wheel	28	DJ199-01B	Oscillator Gear Ret.
4	DJ106-01F	Flat Washer	16	DJ012-01F	Crank Gear	29	AJ057-01A	Retainer Screw
5	DJ021-01N	Spool (empty)	17	CJ014-01A	Anti-Reverse Drag	30	AZ028-01E	Ball Bearing
6	DJ040-01D	Spool Washer	18	CJ061-01A	Anti-Reverse Pawl Spring	31	DJ002-01D	Anti-Reverse Activator
7	DJ027-01J	Clutch Ring	19	CJ106-01A	Pawl Spring Washer	32	DJ015-01E	*Center Shaft
8	DJ197-01F	Geared Clutch	20	DJ126-01B	Machine Screw	33	CJ011-01A	*Pinion Gear
9	DJ189-01N	Spool Carrier	21	CJ060-01A	Anti-Reverse Pawl	34	DJ020-01A	*Center Shaft Spring
10	DJ318-02A	Crank Handle Assy. (10-13) (Gold)	22	DJ350-01A	Finger Brake Assy.	35	DJ023-01K	Back Cover Assy.
11	CJ171-01B	Crank Handle Pin	23	DJ054-01K	Clutch Pinion	36	DJ075-01D	Back Cap
12	DJ068-01C	Crank Handle Spacer	24	CJ172-01A	Finger Brake Pin			
			25	DJ301-02A	Body Assy. w/Ball Bearing (Gold)			

*Available as one unit, DJ315-01B Center Shaft Assy.

PLEASE ORDER BY PART NUMBER, NOT KEY NUMBER

Parts should be ordered from the nearest Zebco Warranty Station, Approved Service Center, or you may order direct from the factory.

Reels not under warranty can be serviced at any Zebco Warranty Station, Approved Service Center or by returning the reel to the factory.

We recommend that you insure your reel when mailing it in for repair.

Damage in shipment is not covered by our guarantee.

Be sure to retain your sales slip as proof of purchase date should warranty work become necessary.

How to Remove Spool on the 164

1. LOOSEN DRAG COMPLETELY BY TURNING CLUTCH WHEEL (15) DOWNWARD.
2. HOLD REEL WITH FRONT COVER (1) FACING YOU.
3. REMOVE FRONT COVER (1) BY HOLDING BACK COVER (35) AND TURNING FRONT COVER APPROXIMATELY 1/4 TURN COUNTER-CLOCKWISE.
4. GRIP REEL AND HANDLE (10) FIRMLY AND UNSCREW SPINNERHEAD (2) COUNTERCLOCKWISE AND REMOVE.
5. WITH REEL FACING YOU, PRESS LIGHTLY ON TOP OF SPOOL CLIP (3) AND SPOOL ASSEMBLY (5) AND TURN CLOCKWISE APPROXIMATELY 1/8 TURN.
6. LIFT OFF SPOOL CLIP (3), FLAT WASHER (4), AND SPOOL ASSEMBLY (5).

TO REASSEMBLE USE REVERSE PROCEDURE.

Spools with line available from factory.