


ENERGY 10PTI - EXPLODED



QTY	DESCRIPTION	REF. NO.	QTY	DESCRIPTION	REF. NO.	QTY	DESCRIPTION	REF. NO.
1	DRAG KNOB ASSEMBLY KIT	PT332-10	Q1332-01	RT332-01		20	HANDLE CAP SCREW KIT	RO4073-01
2	SPOOL ASSEMBLY KIT	PT4371-01	Q14371-01	RT4371-01		20A	HANDLE SCREW WASHER	TH105-01
3	DRAG ASSEMBLY KIT	PT4381-01	Q14381-01	RT4381-01		21	GEAR SHAFT BALL BEARING	CH027-01
4	DRAG WASHER KIT	N/A				22	GEAR SHAFT BALL BEARING	CH028-01
5	DRAG RETAINER	N/A				23	BODY COVER	SC023-55
6	DRAG WASHER-CERAMIC	N/A				24	BODY COVER SCREW WASHER	RO142-01
7	DRAG WASHER-KEYED TO MAIN SHAFT	N/A				25	BODY COVER SCREW	SO057-01
8	DRAG WASHER-KEYED TO SPOOL	PT4371-01	Q14371-01	RT4371-01		26	BODY COVER SCREW	SO057-01
9	SPOOL BEARING KIT	Q1Y2	Q1Y1	Q1Y1		27	LINE ROLLER WASHER	PQ102-51
10	4D-SPOOL BEARING WASHER 7/8"	N/A				28	LINE ROLLER BALL BEARING	GH202-01
11	4D-SPOOL BEARING WASHER 7/8"	N/A				29	LINE ROLLER	PQ102-51
12	CLICK GEAR	RO037-01	RO037-01	RO037-01		30	LINE ROLLER COLLAR	PQ307-01
13	MAIN SHAFT BUSHING	RO214-01	RO214-01	RO214-01		31	ARM LEVER ASSEMBLY	AG108-07
14	ROTOR NUT LOCK SCREW	SH008-01	SH008-01	TH008-01		32	ARM LEVER SCREW	GU077-15
15	ROTOR NUT	GH034-01	GH034-01	GH034-01		33	ARM LEVER COVER SCREW	SG142-01
16	E-CLIP	PQ309-55	PQ309-55	SC038-55		34	ARM LEVER COVER WASHER	PO087-01
17	ROTOR ASSEMBLY	PT015-01	PT015-01	RT015-01		35	ARM LEVER COVER WASHER	PO087-01
18	MAIN SHAFT	RO167-01	RO167-01	RO167-01		36	ARM LEVER COVER	RO019-01
19	CLUTCH WASHER	SO396-01	SO396-01	SO396-01		37	KICK LEVER	RO077-01
20	CLUTCH ASSEMBLY	RO139-01	RO139-01	SO139-01		38	ANTI-REVERSE PAWL SCREW	PQ063-01
21	CLUTCH SLEEVE	GH028-10	GH028-10	UK028-01		39	ANTI-REVERSE PAWL	RO063-01
22	PISTON BALL BEARING	PT4071-01	Q14071-01	RT4071-01		40	ANTI-REVERSE PAWL SPRING	PO082-01
23	GEAR ASSEMBLY KIT					41	ANTI-REVERSE CAM SPRING	PO089-01
24	16A-PISTON					42	ANTI-REVERSE CAM SPRING	PO089-01
25	16B-DRIVE GEAR ASSEMBLY					43	ANTI-REVERSE CAM	PT099-01
26	16C-ADJUST WASHER	RO141-01	RO141-01	SO141-01		44	ANTI-REVERSE LEVER	EH158-01
27	17-PISTON BUSHING	PT001-01	Q1001-01	RT001-01		45	OSG GEAR BALL BEARING	EH158-01
28	PISTON BUSHING	RO141-01	RO141-01	RT001-01		46	OSCILLATOR GEAR	PO053-51
29	BODY					47	OSCILLATOR SLIDER	PO025-01
30	BEARING SCREW	RO141-01	RO141-01	RT001-01		48	MAIN SHAFT SCREW	PQ140-55
						49	BODY REAR COVER	RO062-02
						50	HANDLE REAR COVER SCREW	PT318-51
						51	HANDLE ASSEMBLY	Q1318-51