


QUANTUM BR1/3-40



KEY NO.	BR140 PART NO.	BR340 PART NO.	DESCRIPTION	PRICE	KEY NO.	BR140 PART NO.	BR340 PART NO.	DESCRIPTION	PRICE
1	BH321-21	BH321-22	SPOOL ASSY.	7.75	28	BH046-21	BH046-21	ARM LEVER COVER	2.10
2	BH081-21	BH081-21	SPOOL WASHER 'A'	.55	29	BH085-11	BH085-11	COVER SCREW	.60
3	BH033-21	BH033-21	SPOOL WASHER 'B'	.55	30	BH007-11	BH007-12	ARM LEVER	3.00
4	BH080-21	BH080-21	SPOOL WASHER 'D'	.90	31	BH044-11	BH044-11	ARM LEVER SCREW	.60
5	BH038-21	BH038-21	DRAG RETAINER	.95	32	BH024-11	BH024-11	BAIL HOLDER COVER	1.55
6	BH332-21	BH332-21	DRAG KNOB ASSY.	3.10	33	BH085-11	BH085-11	COVER SCREW	.60
7	BH001-21	BH001-22	BODY	6.00	34	BH347-22	BH347-22	BAIL ASSY.	5.40
8	BH027-11	BH027-12	BEARING	5.95	35	BH016-11	BH016-11	LINE ROLLER BUSHING	1.00
9	BH090-11	BH090-11	STOPPER CAM	1.50	36	BH004-11	BH004-11	LINE ROLLER	5.30
10	BH089-11	BH089-11	STOPPER CAM SPRING	.90	37	BH044-11	BH044-11	BAIL HOLDER SCREW	.60
11	BH059-11	BH059-11	STOPPER LEVER	1.05	38	BH108-11	BH108-11	BAIL SCREW	.60
12	BH135-11	BH135-11	STOPPER LEVER SCREW	.60	39	BH110-11	BH110-11	BEARING WASHER	.50
13	BH061-11	BH061-11	STOPPER SPRING	1.40	40	BH086-11	BH086-11	SILENT SPRING	1.55
14	BH063-11	BH063-11	STOPPER	1.45	41	BH060-11	BH060-11	RATCHET GEAR	1.55
15	BH077-11	BH077-11	STOPPER SCREW	.60	42	BH006-11	BH006-11	ROTOR NUT	1.05
16	BH011-11	BH011-11	PINION GEAR	3.15	43	BH094-11	BH094-11	ROTOR NUT LOCK SCREW	.60
17	BH028-11	BH028-11	BALL BEARING	8.20	44	BH315-21	BH315-21	MAIN SHAFT ASSY.	5.85
18	BH041-11	BH041-11	BEARING SCREW	.60	45	BH100-11	BH100-11	MAIN SHAFT SCREW	.60
19	BH053-21	BH053-21	O/S GEAR	1.45	46	BH012-11	BH012-11	DRIVER GEAR	5.25
20	BH025-11	BH025-11	O/S SLIDER	2.50	47	BH026-11	BH026-11	ADJUST WASHER	.65
21	BH009-21	BH009-22	ROTOR	5.50	48	BH027-11	BH027-12	BEARING	5.95
22	BH049-21	BH049-21	KICK LEVER SPRING	.90	49	BH023-21	BH023-22	BODY COVER	3.25
23	BH019-21	BH019-21	KICK LEVER	1.80	50	BH057-11	BH057-11	BODY COVER SCREW	.60
24	BH136-11	BH136-11	KICK LEVER SCREW	.60	51	BH318-11	BH318-11	HANDLE ASSY.	6.00
25	BH020-11	BH020-11	SPRING HOLDER	.90	52	BH105-11	BH105-11	HANDLE CAP WASHER	.45
26	BH022-21	BH022-21	ARM LEVER SPRING	.60	53	BH073-11	BH073-11	HANDLE SCREW CAP	2.20
27	BH031-21	BH031-21	SPRING SHAFT	.90					

Prices subject to change without notice. Prices do not include postage and handling.

PLEASE ORDER BY PART NUMBER

Rev. 6/94

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

