


QUANTUM GW80



Key No.	Part No.	Description	Price	Key No.	Part No.	Description	Price
1	BH321-53	Spool Assembly	7.75	28	BH060-51	Ratchet	1.20
2	BH080-51	Drag Washer	1.55	29	BH028-51	Ball Bearing	7.50
3	BH033-51	Lining Washer	.60	30	BH040-51	Bearing Plate	1.20
4	BH081-51	Spool Washer	.90	31	BH110-51	Pinion Collar	1.20
5	BH038-51	Stop Ring	1.00	32	BH077-51	Bearing Screw	.50
6	BH332-53	Drag Knob Assembly	3.25	33	BH063-51	Stopper	1.20
7	BH009-53	Rotor	6.50	34	BH099-51	Stopper Screw	.50
8	BH022-51	Bail Arm Spring	1.00	35	BH061-51	Stopper Spring	1.40
9	BH046-53	Bail Arm Cover	1.00	36	BH059-53	Anti-Reverse Lever	1.00
10	BH077-53	Bail Arm Cover Screw	.50	37	BH089-51	Leaf Spring	1.00
11	BH161-51	Bail Arm Boss Collar	1.20	38	BH315-51	Main Shaft Assembly	2.90
12	BH007-53	Bail Arm	1.55	39	BH030-51	Sheet Washer	.90
13	BH019-51	Kick Lever	1.55	41	BH053-51	Oscillating Gear	1.55
14	BH024-53	Bail Holder Cover	1.00	42	BH025-51	Oscillating Slider	2.05
15	BH347-53	Bail Assembly	3.10	43	BH100-51	Oscillating Screw	.50
16	BH004-53	Line Roller Ball Bearing	2.60	44	BH012-51	Main Gear	3.05
17	BH162-53	Roller Washer	.50	45	BH026-51	Gear Washer	1.00
18	BH108-53	Roller Screw	.90	46	BH023-53	Body Cover	2.60
19	BH017-53	Bail Holder	2.60	47	BH057-53	Body Cover Screw-A	.50
20	BH044-53	Bail Holder Screw	.90	48	BH163-53	Body Cover Screw-B	.50
21	BH065-51	Lock Washer	.50	49	BH318-53	Handle Assembly	7.00
22	BH006-51	Rotor Nut	1.20	50	BH073-53	Handle Cap	1.20
23	BH094-51	Rotor Nut Screw	.60	51	BH105-51	Handle Cap Washer	.90
25	BH001-53	Body	6.50				
26	BH027-52	Bearing	7.50				
27	BH011-51	Pinion	3.15				

Prices subject to change without notice. Prices do not include postage and handling.

PLEASE ORDER BY PART NUMBER

Rev. 6/95

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

