

MS00XL PARTS LIST

Key No.	Part No.	Description	Key No.	Part No.	Description
1	ZU332-3	Drag Knob Ass'y	31	ZU011	Pinion Gear
2	KQ038	Drag Retainer	32	GU077	Bearing Screw
3	ZU080	Spool Washer "D"	33	GU073-6	Handle Screw Cap
4	KQ029	Spool Washer "B"	34	GU105	Handle Cap Washer
5	KQ045	Spool Washer "A"	35	GU001-10	Body
6	ZU321-3	Spool Ass'y	36	GU090-2	A/R Lever
7	GU105-6	Spool Washer	37	GU089	Stopper Lever Spring
8	AQ037	Spool Click Claw	38	GU091	Stopper Bushing
9	GU006	Rotor Nut	39	GU061	Stopper Spring
10	GU077-3	Kick Lever Cover Screw	40	GU063	Stopper "A"
11	ZU046-3	Kick Lever Cover	41	GU074	Stopper "B"
12	ZU019	Kick Lever	42	GU077-5	Stopper Screw
13	KQ049	Kick Lever Spring	43	GU157	Ball Bearing
14	GU077-4	Rotor Nut Lock Screw	44	GU012	Drive Gear
15	KQ034	"E"-Clip	45	GU086	Silent Cam
16	KQ034	"E"-Clip	46	GU105-8	Drive Gear Adj. Washer
17	KQ108-3	Bail Screw	47	GU157-2	Ball Bearing
18	ZU007	Arm Lever	48	ZU053	O/S Gear
19	GU051-7	Arm Lever Pin	49	GU025	O/S Slider
20	EQ017-2	Bail Collar	50	GU100	Main Shaft Screw
21	EQ004	Line Roller B.B.	51	GU023-10	Body Cover
23	ZU347-3	Bail Ass'y	52	GU057-2	Body Cover Screw
24	KQ031	Spring Shaft	53	ZU318	Handle Ass'y
25	KQ049-3	Arm Lever Spring	54	ZU015	Main Shaft
26	QL020	Spring Holder	55	ZU009-3	Rotor
27	ZU087-3	Arm Lever Spring Cover	56	ZU109	Washer
28	GU077-3	Arm Lever Spring Cover Screw	57	GU157	Ball Bearing
29	AQ028	Ball Bearing	58	ZU139	Bearing Sleeve
30	GU060	Ratchet Gear			

MS1XL PARTS LIST

Key No.	Part No.	Description	Key No.	Part No.	Description
1	GU332-5	Drag Knob Ass'y	31	GU011	Pinion Gear
2	GU038	Drag Retainer	32	GU077	Bearing Screw
3	GU080	Spool Washer "D"	33	GU073-6	Handle Screw Cap
4	GU105-5	Spool Washer "B"	34	GU105	Handle Cap Washer
5	GU081	Spool Washer "A"	35	GU001-9	Body
6	XU321-2	Spool Ass'y	36	GU090-2	A/R Lever
7	GU105-6	Spool Washer	37	GU089	Stopper Lever Spring
8	AQ037	Spool Click Claw	38	GU091	Stopper Bushing
9	GU006	Rotor Nut	39	GU061	Stopper Spring
10	GU077-3	Kick Lever Cover Screw	40	GU063	Stopper "A"
11	GU046-3	Kick Lever Cover	41	GU074	Stopper "B"
12	GU019	Kick Lever	42	GU077-5	Stopper Screw
13	KQ049	Kick Lever Spring	43	GU157	Ball Bearing
14	GU077-4	Rotor Nut Lock Screw	44	GU012	Drive Gear
15	KQ034	"E"-Clip	45	GU086	Silent Cam
16	KQ034	"E"-Clip	46	GU105-8	Drive Gear Adj. Washer
17	KQ108-3	Bail Screw	47	GU157-2	Ball Bearing
18	ZU007	Arm Lever	48	GU053	O/S Gear
19	GU051-7	Arm Lever Pin	49	GU025	O/S Slider
20	EQ017-2	Bail Collar	50	GU100	Main Shaft Screw
21	EQ004	Line Roller B.B.	51	GU023-9	Body Cover
23	ZU347-4	Bail Ass'y	52	GU057-2	Body Cover Screw
24	KQ031	Spring Shaft	53	ZU318	Handle Ass'y
25	KQ049-3	Arm Lever Spring	54	GU015	Main Shaft
26	QL020	Spring Holder	55	GU009-7	Rotor
27	LU087-3	Arm Lever Spring Cover	56	ZU109	Washer
28	GU077-3	Arm Lever Spring Cover Screw	57	GU157	Ball Bearing
29	AQ028	Ball Bearing	58	ZU139	Bearing Sleeve
30	GU060	Ratchet Gear			