

ENERGY BAITCAST E400 / E500 / E500CP / E600TI PARTS LIST

E400	E500	E500 CP	E600TI	Description
ZW023-01	ZW023-02	ZW023-04	ZW023-03	Left Side Cover
ZW108-01	←	←	←	Clicker
ZW026-01	ZW026-01	ZW026-01	ZW026-02	Magnet Ball
NX105-01	←	←	←	Dial Friction Ring
ZW028-01	←	←	←	Slide Cam
NX071-01	←	←	←	Slide Cam Spring
ZW051-01B	←	←	←	Spool Cover
ZW125-01	←	←	←	Spool Cover Screw
OMW035-04	←	←	←	Spool Tension Shim
SW117-01	←	←	←	Ball Bearing - Spool Shaft
OMW090-01	←	←	←	Clip Ring
OMW330-01	←	←	←	Magnet Plate Assy
OMW076-01	←	←	←	Magnet Plate Screw
ZW521-01B	←	←	←	Spool Assy
ZW027-01	ZW027-02	ZW027-04	ZW027-03	Front Support
NX092-01	←	←	←	Worm Shaft E-Clip
OMW035-03	←	←	←	Worm Shaft Washer
OMW067-01	←	←	←	Worm Shaft Bushing
ZW347-01	ZW347-01	ZW347-03	ZW347-02	Line Guide Carrier Assy
ZW006-01	ZW006-01	ZW006-01	ZW006-02	Line Guide Pawl
OMW035-03	←	←	←	Line Guide Pawl Washer
ZW007-01	ZW007-01	ZW007-02	ZW007-02	Pawl Cap Screw
ZW016-01	←	←	←	Worm Shaft Guide
ZW072-01	←	←	←	Worm Shaft
ZW085-01	←	←	←	Oscillate Pinion Gear
NX090-01	←	←	←	Oscillate Pinion Gear E-Clip
ZW061-01	←	←	←	Stabilizer Bar
OMW080-01	←	←	←	Clip Ring
SW017-01	←	←	←	Ball Bearing - Spool Shaft
ZW056-01	ZW056-01	ZW056-02	ZW056-02	Thumb Bar Retainer
ZW309-01	ZW309-01	ZW309-02	ZW309-02	Thumb Bar Assy
ZW301-01	ZW301-01	ZW301-03	ZW301-02	Frame Assy
ZW07-01	←	←	←	Kick Lever
OMW120-01	←	←	←	Pinion Yoke Shaft E-Clip
ZW311-01	VW311-01	RW311-01	VW311-01	Pinion Yoke Assy
OMW120-01	←	←	←	Pinion Yoke Shaft E-Clip
ZW025-01	←	←	←	Pinion Yoke
OMW040-01	←	←	←	Pinion Yoke Spring
ZW097-01	←	←	←	Kick Lever Spring
ZW024-01	ZW024-02	ZW024-04	ZW024-03	Right Side Cover

ENERGY BAITCAST E400 / E500 / E500CP / E600TI PARTS LIST

Key					
No.	E400	E500	E500CP	E600TI	Description
41	OM192-01	←	←	←	Right Side Cover Screw
42	OM101-01	←	←	←	Spool Tension Knot O-Ring
43	OM117-01	OM117-01	OM117-01	SM117-01	Tension Knob Bearing
44	OMW032-04	←	←	←	Spool Tension Washer
45	OMW081-01	←	←	←	Spool Tension Collar
46	OMW082-01	←	←	←	Spool Cushion Washer
47	ZW033-01	ZW033-01	ZW033-02	ZW033-02	Spool Cushion Knob
48	ZW039-01	←	←	←	Release Slider
49	ZW039-01	←	←	←	Thumb Bar Screw
50	ZW104-01	←	←	←	Release Slider Spring
51	SM121-01	←	←	←	Release Slider Guide E-Clip
52	NX090-01	←	←	←	Release Slider Lower Bearing
53	ZW017-01	SW017-01	←	←	Crank Shaft Lower Bearing
54	OM120-01	←	←	←	Crank Shaft E-Clip
55	ZW002-01	←	←	←	Crank Shaft Retainer
56	TM107-01	←	←	←	Crank Shaft Retainer Screw
57	ZW008-01	←	←	←	Crank Shaft
58	ZW112-01	←	←	←	Oscillate Drive Gear
59	OMW083-01	←	←	←	Tip Hatchet
60	OM111-01	←	←	←	Tip Hatchet Washer
61	ZW012-01	VW012-01	←	←	Drive Gear
62	OMW056-01	←	←	←	Drag Disc
63	OMW045-01	←	←	←	Drag "D" Washer
64	OMW052-02	←	←	←	One Way Bearing
65	UC063-02	←	←	←	One Way Bearing Sheave
66	TMW058-01	←	←	←	Crank Shaft Ball Bearing
67	TMW035-02	←	←	←	Crank Shaft Washer
68	OMW046-02	←	←	←	Spring "D" Washer
69	ZW055-01	ZW055-01	VW395-01	VW395-01	Star Drag
70	OMW054-01	←	←	←	Handle Washer
71	ZW318-01	ZW318-01	ZW318-02	ZW318-02	Handle Assy
72	OMW033-01	←	←	←	Handle Nut
73	OMW034-01	ZW034-01	ZW034-02	ZW034-02	Handle Nut Cap
74	ZW130-01	ZW130-01	ZW130-02	ZW130-02	Line Indicator
75	OM123-01	←	←	←	Handle Nut Cap Screw
76	ZM119-01	←	←	←	Slide Cover Locking Lever
77	ZW096-01	←	←	←	Locking Lever Spring
78	N/A	N/A	ZW110-01	ZW110-01	Drag Click Spring
79	N/A	N/A	ZW114-01	ZW114-01	Drag Click Spring Retainer
80	N/A	N/A	ZW032-01	ZW032-01	Star Drag Washer