

EX500 Parts List

KEY PART NO.	PART NO.	DESCRIPTION	KEY PART NO.	PART NO.	DESCRIPTION
1	QW/023-4	Left Side Cover	40	QW/032-1	Washer - Spool Tension
2	QW/108	Clicker	41	QW/081	Collar
3	QW/125	Screw - Clicker	42	QW/082	Cushion Washer - Spool
4	QW/026-2	Magnet Control Dial	43	QW/033	Spool Tension Knob
5	NX105	Dial Friction Ring	44	QW/073	Ring - Thumb Screw Ret.
6	QW/028	Slide Cam	45	QW/374	Thumb Screw
7	NX071	Slide Cam Spring	46	QW/125	Screw - Spool Cover
8	QW/051	Spool Cover	47	QW/076	Screw - Magnet Ring
9	QW/032-1	Spool Tension Shim	48	SW/009	Thumb Rest
10	SW/017	Bearing	49	SW/087	Flippin' Switch
11	QW/080	Clip Ring	50	QW/097	Spring - Kick Lever
12	QW/330	Magnet Plate Assy.	51	SW/039	Release Slider
13	QW/027-7	Hood	52	QW/076	Screw Release Slider
14	NX092	E-Clip (Worm Shaft)	54	SW/104	Spring - Release Slider
15	QW/035-3	Washer (Worm Shaft)	55	SW/050	Thumb Bar Retaining Screw
16	QW/067	Worm Shaft Bushing	56	SW/017	Bearing - Crankshaft
17	QW/347	Line Guide Carrier	57	QW/120	E-Ring - Crankshaft
18	QW/006	Line Guide Pawl	58	QW/002	Retainer - Crankshaft
19	QW/035-3	Washer (L/G Pawl)	59	QW/107	Screw - Crankshaft Retainer
20	QW/007	Line Guide Carrier Screw	60	QW/008	Crankshaft
21	QW/016	Worm Shaft Guide	61	QW/083	Trip Ratchet
22	QW/072	Worm Shaft	62	QW/111	Washer
23	QW/085	Level Wind Gear	63	QW/112	Gear - LW/ Idler
24	NX090	E-Ring (LW/ Gear)	64	SW/012	Drive Gear
25	QW/061	Stabilizer Bar	65	QW/059	Drag Disc
26	NX090	E-Ring (Stabilizer Bar)	66	QW/045	Drag Washer
27	QW/099-6	Front Support	67	QW/052	Clutch Sleeve
28	QW/321	Spool Assy.	68	QW/063	Anti-Reverse Clutch
29	SW/017	Bearing	69	TW/058	Bearing - Crankshaft Top
30	SW/001	Frame	70	TW/035-2	Washer - Crankshaft
31	SW/077	Kick Lever	71	QW/046-2	Spring "D" Washer
32	QW/120	E-Ring (Kick Lever)	72	QW/055	Drag Star
33	SW/311	Pinion Gear	73	QW/054	Handle Washer
34	SW/025	Pinion Yoke	74	QW/318	Handle Assy.
35	QW/040	Spring-Pinion Yoke	75	QW/003	Handle Nut
36	SW/024-1	Right Side Cover	76	QW/034	Handle Nut Cap
37	QW/053-1	Screw (Rt. Side Cover)	77	QW/123	Handle Nut Cap Screw
38	QW/101	Tension Knob Ring	78	SW/121	Washer - Release Slider
39	SW/117	Bearing	79	SW/094	Spacer