# SHIMANO

## 1997 Repair Supplemer




# STRADIC 4000FE 97

### ST4000FE

| Part # | Description | Part # | Description | Part # | Description |
|---|---|---|---|---|---|
| RD 0026 | Ball Bearing | RD 4637 | Line Roller Spacer | RD 4822 | Main Shaft |
| RD 0041 | Drive Gear Washer | RD 4638 | Line Roller Washer | RD 4823 | Bail Arm |
| RD 0071 | Rotor Nut | RD 4639 | Spacer | RD 4824 | Bail Spring Cover |
| RD 0787 | Multi-Purpose Screw | RD 4650 | Bail Hold Support Shaft | RD 4825 | Bail Hold Support Guard |
| RD 0930 | Ball Bearing | RD 4652 | Lever Spring Guide (B) | RD 4826 | Bail Hold Support Spacer |
| RD 1008 | Handle Lock Washer | RD 4654 | Lever Spring Guide (A) | RD 4828 | Rotor |
| RD 1506 | Clutch Cover Screw | RD 4656 | Trip Lever Spacer | RD 4829 | Roller Clutch Screw |
| RD 1520 | Anti-Reverse Cam Spring | RD 4661 | Anti-Reverse Cam Ring | RD 4830 | Pinion Gear |
| RD 1891 | Multi-Purpose Screw | RD 4675 | Oscillating Pawl Cover Screw | RD 4831 | Ball Bearing |
| RD 2298 | Spacer | RD 4677 | Oscillating Slider Bushing | RD 4832 | Anti-Reverse Cam |
| RD 2309 | Slider Retainer Screw | RD 4678 | Oscillating Pawl | RD 4833 | Word Bushing (Front) |
| RD 2362 | Spool Support | RD 4698 | Bail Spring Guide (A) | RD 4834 | Idle Gear |
| RD 2404 | "E" Lock | RD 4699 | Bail Spring | RD 4835 | Worm Shaft |
| RD 2852 | Handle Screw Lock | RD 4700 | Bail Spring Guide (B) | RD 4836 | Worm Bushing (Rear) |
| RD 3081 | Side Cover Screw | RD 4701 | Bail Arm Screw | RD 4837 | Side Cover Flange |
| RD 3304 | Bearing Spacer | RD 4702 | Bail Arm Bushing | RD 4838 | Drive Gear Bushing |
| RD 3306 | Line Roller Bearing | RD 4704 | Bail Spring Cover Screw (LG) | RD 4839 | Drive Gear |
| RD 3309 | Line Roller Screw | RD 4710 | Lever Spring | RD 4840 | Side Cover |
| RD 3366 | Anti-Reverse Lever Screw | RD 4711 | Bail Trip Lever | RD 4841 | Body |
| RD 3402 | Bail Spring Cover Screw (Sm) | RD 4714 | Roller Clutch Assembly | RD 4842 | Oscillating Guide (A) |
| RD 3414 | Drag Knob | RD 4733 | Oscillating Pawl Cover | RD 4843 | Oscillating Guide (B) |
| RD 3468 | Rear Cover Screw (Short) | RD 4734 | Oscillating Slider | RD 4844 | Worm Shaft Retainer |
| RD 3503 | Spool Washer | RD 4803 | Worm Shaft Spacer | RD 4845 | Rear Cover |
| RD 4417 | Line Roller | RD 4810 | Rear Protector Screw | RD 4846 | Rear Protector |
| RD 4421 | Handle Screw Cap | RD 4814 | Anti-Reverse Lever | RD 4847 | Handle Assembly |
| RD 4636 | Line Roller Bushing | RD 4821 | Spool Assembly | RD 5357 | Bail Assembly |