Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SPINNING REEL *DYNASPIN*

GH3000(P-G) / GH3000(P-BL)
GH3500(P-G) / GH3500(P-BL)



Key NO.	Parts No.	Parts name
1	2YD-089-02	DRAG KNOB ASSEMBLY
2	2E4-034-01	DRAG WASHER RETAINER
3	2W2-071-01	KEY WASHER
4	2W1-226-01	080-260 WASHER
5	2W3-035-01	EARED WASHER
6	2YT-415-02	SPOOL TOTAL ASSEMBLY
7	2W2-016-01	KEY WASHER
8	2Z1-029-05	408-3 BALL BEARING
9	2C1-119-01	SPACER
10	2W1-053-01	080-185 WASHER
11	2L3-015-01	CLICK LEAF SPRING
12	2M3-120-01	MAIN SHAFT
13	2F8-019-02	CLICK LEAF SPRING HOLDER
14	2W2-015-01	KEY WASHER
15	2E3-007-01	ROTOR NUT
16	2E1-036-01	B26-040 SCREW
17	2R1-137-02	ROTOR
18	2R5-164-01	BAIL PAWL
19	2R4-185-02	BAIL TRIP COVER
20	2E1-015-02	B26-060 SCREW
21	2E2-007-01	B30M-100 SCREW
22	2E1-010-01	b30-100 SCREW
23	2R2-062-02	BAIL ARM
24	2C1-034-01	LINE ROLLER COLLAR
25	2Z1-012-05	407-2.5 BALL BEARING
26	2R6-020-01	LINE ROLLER
27	2C2-032-01	LINE ROLLER BUSH
28	2YL-146-02	BAIL ASSEMBLY
29	2R5-135-01	BAIL TRIP SHAFT
30	2W1-199-01	015-027 WASHER
31	2Q1-096-01	BAIL SPRING
32	2C2-119-01	BAIL SPRING GUIDE
33	2R4-184-02	BAIL SPRING COVER
34	2A4-021-01	ONE-WAY CLUTCH INNER TUBE
35	2E2-047-02	A20M-065 SCREW
36	2F8-079-01	ANTI-REVERSE SPRING ANCHOR
37	2F5-192-01	ROLLER CLUTCH RETAINER
38	2Q2-016-01	SPRING
39	2YZ-014-01	ONE-WAY CLUTCH BEARING ASSEMBLY
40	2E2-052-01	F26M-080 SCREW
41	2F5-193-01	BEARING RETAINER
42	2Z1-003-05	714-5 BALL BEARING
43	2G2-155-01	PINION GEAR
44	2A2-031-01	ANTI-REVERSE CAM
45	2Q3-009-01	ANTI-REVERSE SPRING
46	2YB-206-04	BODY ASSEMBLY
47	2B2-110-05	BODY COVER(R)
48	2Z1-010-05	812-3.5 BALL BEARING
49	2M2-016-01	OSCILLATING CAM
50	2G3-081-01	OSCILLATING GEAR
51	2M1-057-01	OSCILLATING SILDER
52	2E5-051-01	OSCILLATING SILDER RETAINER
53	2E2-009-02	F23M-060 SCREW
54	2E1-020-02	B22-055 SCREW
55	2G3-068-01	DRIVE PINION
56	2G1-141-01	DRIVE GEAR
57	2W1-019-00	071-103 WASHER
58	2Z1-039-05	713-4 BALL BEARING
59	2B2-111-05	BODY COVER(L)
60	2E1-005-02	A26-120 SCREW
61	2YH-347-01	HANDLE ASSEMBLY
62	2C3-042-01	HANDLE SCREW SLEEVE
63	2W1-004-01	029-080 WASHER
64	2H6-017-02	HANDLE SCREW CAP
65	2E2-013-02	B20M-060 SCREW
66	2A1-033-03	ANTI-REVERSE LEVER
67	2F5-389-02	REAR COVER
68	2E2-051-01	B23M-060 SCREW
GH3000(P-BL)	SPECIAL PARTS	
1	2YD-089-03	DRAG KNOB ASSEMBLY
6	2YT-415-03	SPOOL TOTAL ASSEMBLY
19	2R4-185-03	BAIL TRIP COVER
26	2R6-020-02	LINE ROLLER
28	2YL-146-03	BAIL ASSEMBLY
33	2R4-184-03	BAIL SPRING COVER
67	2F5-389-03	REAR COVER
GH3500(P-G)	SPECIAL PARTS	
6	2YT-437-02	SPOOL TOTAL ASSEMBLY
GH3500(P-BL)	SPECIAL PARTS	
1	2YD-089-03	DRAG KNOB ASSEMBLY
6	2YT-437-03	SPOOL TOTAL ASSEMBLY
19	2R4-185-03	BAIL TRIP COVER
26	2R6-020-02	LINE ROLLER
28	2YL-146-03	BAIL ASSEMBLY
33	2R4-184-03	BAIL SPRING COVER
67	2F5-389-03	REAR COVER